

Connection Details for NC601B Internet Server

Terminals on small PCB	Thermostat Connections
T+/A	Not needed
T-/B	B on Thermostats
R+	Y on Thermostats
R-	Not needed
GND	Not needed
+9V	Not needed